

1. Components

Table of Components for AIS Model JHS-182

No.	Name	Type	Quantity	Mass 1Unit (kg)	Remarks
	Standard Components				
1	AIS Transponder	NTE-182	1	2.6	With 1 whip antenna and 2 fitting bands
2	Coaxial Connector	N-P-10U	1	0.08	Attached to item 1
3	AIS Controller	NCM-779	1	1.0	With 4 tapping screws
4	Attached Cable	7ZCJD0214A	1	0.6	Cable length=10m
5	Connection Box	NQE-3182	1	2.5	With 4 tapping screws
6	Spare Parts	7ZXJD0049	1	0.04	
	Option(s)				
7	Power Supply Unit	NBD-577C	1	5.4	For AC operation
8	Pilot Plug Box	NQE-3150	1	0.4	Wall mounting type
9	Console Mounting Kit for NQE-3150	MPBX40498A	1	0.3	
10	Output Buffer	NQA-4251	1	0.8	