



50

51314-01S

Starting Valve

Plate  
Page 2(2)

L23/30H

Item No.	Qty	Designation	Item No.	Qty	Designation
1	1/V	Body			
7	1/V	Solenoid			
11	1/V	Solenoid fixture			
21	1/V	Pilot valve			
31	1/V	Bolt			
38	2/V	Spool assy			
50	1/E	Main starting valve, complete			

When ordering spare parts, see also page 600.50.

\* = Only available as part of a spare parts kit.

Qty./E = Qty./Engine

Qty./V = Qty./Valve

08028-0D/H5250/94.08.12