


A - A



Item No.	Item Description	Item No.	Item Description
018	Ball valve		
031	Stud		
043	Nut		
055	Hydraulic block		
067	Plug screw		
079	Intermediate pipe		
080	O-ring		
102	Membrane accumulator ✓		
114	Gasket		
138	Coupling		
151	Hydraulic block		
187	Stud		
199	Ball valve		
222	Screw		
305	Lubricator		
317	Screw		
329	Non-return valve		
330	O-ring		
342	Adjusting screw		
354	Coupling		
366	Distance pipe		
378	Cover		
391	Cylinder block		
413	O-ring		
425	O-ring		
437	Screw		
449	O-ring		
462	Plug		
474	Screw		
486	Inductive sensor		
498	Cabel gland, complete		
521	Plunger		
533	Spring		
557	Cylinder housing		
569	Plunger		
582	Plug		
594	O-ring		
604	Housing		
616	O-ring		
641	Solenoid valve, complete		
653	Screw		
677	Cable		
689	Cable gland, complete		
690	Membrane accumulator ✓		
700	Gasket		