


Fuel Pump Side View of KTA 19 M (Heat Exchanger Cooled)



- 1. Coolant Expansion Tank Cap
- 2. Coolant Expansion Tank
- 3. Coolant Outlet Connection
- 4. Engine Crankcase Breather
- 5. Aftercooler
- 6. Intake Manifold
- 7. Intake Air Crossover
- 8. Intake Air Supply Tube
- 9. Valve Cover
- 10. Air Cleaner Cap
- 11. Air Cleaner
- 12. By-pass Oil Filter
- 13. Magnetic Pickup Location
- 14. Flywheel Housing
- 15. Marine Gear Oil Fill and Breather
- 16. Marine Gear Oil Filter
- 17. Marine Gear Lifting Eye
- 18. Marine Gear
- 19. Fuel Inlet Fitting 7/8-14 UNF-2A TH'D
- 20. Marine Gear Support
- 21. Marine Gear Oil Drain
- 22. Rear Engine Support
- 23. Oil Pan Drain
- 24. Full Flow Lube Oil Filters
- 25. Oil Pan
- 26. Engine Crankcase Ventilation Tube
- 27. Engine Oil Fill Location
- 28. Engine Oil Dipstick
- 29. Fuel Filters
- 30. Fuel Return Check Valve
- 31. Fuel Supply Check Valve
- 32. Fuel Pump
- 33. Front Engine Support
- 34. Hydraulic Pump Location
- 35. Fuel Pump Throttle Lever
- 36. Tachometer Drive Take-off
- 37. Raw Water Pump
- 38. Raw Water Inlet Connection
- 39. Zinc Plugs
- 40. Raw Water Outlet Connection
- 41. Coolant Heat Exchanger
- 42. Coolant Level Sight Glass