

		<b>H17/28</b>	Page 2/2
<b>L.O Pump Assembly</b>	<b>Assembly Drawing &amp; Part List</b>	Section No.	Rev.
윤활유 펌프 어셈블리	조립도 및 부품 목록	<b>S61000</b>	<b>1A</b>

### Part List

Item No.	Description	Q'ty / Cyl.	Weight (kg)	Remarks / See Note
100	Lubricating oil pump complete	1		
210	Pump housing	1		
202	Pump cover	1		
203	Gear wheel (L)	1		
204	Gear wheel (S)	1		
205	Spur gear	1		
206	Washer	1		
207	Bolt	1		
208	Bush	3		
209	Bush	1		
210	Pin	2		
211	Plug	1		
212	Bolt	5		
213	O-ring	1		
214	O-ring	1		
191	Stud bolt	6		
192	Nut	6		
193	Parallel pin	2		