

# SPARE PARTS


## 7.4 FILTERING UNIT

### 7.4.1 Parts list and exploded view



Item	Article No	Name	Material	Qty
16	See 7.4.3	Distributor	Aluminium	1
18	See 7.4.3	Sleeve	Aluminium	1
21	1800-07679	Driving pin	Steel	1
22	1800-06921	Ball bearing	Steel	1
23	1800-06147	Circlip	Steel	1
24	1800-01708	Diversion cover	Aluminium	1
25	1800-01709	Diversion companion spacer	Aluminium	1
26	1800-01710	Spacer	Aluminium	1
27	1800-01711	Full flow companion spacer	Aluminium	1
28	1800-01712	Full flow cover	Aluminium	1
29	See 7.4.4	Diversion filter element	Aluminium + Stainless steel	*
30	See 7.4.4	Full flow filter element		*
31	1800-06155	Washer	Steel	4
	1800-06445	Screw	Steel	4
32	See 7.4.5	Assembling rod	Steel	4
33	1800-06441	Screw	Steel	8
34	1800-06155	Washer	Steel	8
38	1800-06526	Screw	Steel	8
	1800-08150	Spring guide	Steel	
	1800-06355	Spring	Steel	
42	1800-05416	O-ring	Nitril	3
43	1800-05413	O-ring	Nitril	1

\* According to filter size (See 8.1)

# SPARE PARTS



1FU-028



1FU-058

*Filtering unit*