



Item No.	Part Description	Item No.	Part Description
000	Fuel pump, complete	627	Cover
029	Packing ✓	639	Sealing ring ✓
042	Gasket	640	Sealing ring
054	Plug screw	652	Puncture valve, complete
078	Pump housing, complete	664	Air piston
101	Timing guide	676	Gasket
113	Sleeve	688	Valve housing
125	Regulating guide	711	O-ring
137	Guide pin	723	Slide
149	Screw	735	Spring
150	Stud	747	Spring guide
162	Guide pin	772	Throttle plug
174	Gasket	784	Gasket
186	Guide screw	796	Sealing ring
198	Throttle plug	843	Protective cap
208	Guide pin	855	Screw
221	Guide bushing, complete	879	Coupling
257	Screw	880	Pipe
269	Screw	892	Banjo coupling
270	Top cover	902	Plug screw
282	Lock washer ✓	914	Disc
389	Nut	926	Pipe
390	Screw		
400	Spring guide		
412	Spring		
436	Suction valve, complete		
448	Slide		
461	Thrust piece		
473	Sealing ring ✓		
520	Sealing ring ✓		
532	Pump barrel		
544	Pump barrel, complete		
556	Plunger		
603	Screw		
615	Lock washer		

FUEL PUMP PLATE 90901-14