

Item No.	Part Description
000	Exhaust valve, complete
013	Sealing ring
025	Sealing ring
049	Cover
050	Screw
062	Packing
086	Packing
098	Flange
121	Screw
133	O-ring
145	Bottom piece
169	Exhaust valve spindle
182	Screw
182	Sealing ring
204	Spindle guide-lower
228	Thread insert
241	Exhaust valve housing
253	Packing
265	Plug screw
300	Sealing ring

For sealing oil system

